
For Models: KBRA20ELWH01, KBRA20ELBT01, KBRA20ELBL01, KBRA20ELSS01, KBLA20ELSS01
(White) (Biscuit) (Black) (Stainless Steel-RH)(Stainless Steel-LH)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8171102 8170954	Literature Parts Tech Sheet Use & Care Guide Guide, Energy Plug, Button (3)	16	4344187 4344188 8170858	Shim, Center Hinge White Black Cover, Corner	29 30 31	8171076 8171077	Track, Door Left Right Cover, Unit
4	4344209 8170487 4344208 8170924	White Biscuit Black	18	8170859 8170860 8171078	White Bracket, Slide(2)	32 33 34 35	8170899	Power Cord Insulation, Sound Slide, Drawer(2) Bolt, Adjusting
5 6 7	8170886 8170869 8171013	Roller Assembly Clip, Grille Pin, Center Hinge	19	8171079 8171067	Right Hinge Bottom White	36 37	8171100 8170861	(Rear) Clip, Cord Tube, Drain
8 9 10	4343675 4343715 8171004	Screw Hinge Cover, Bottom	20 22	8171066 8170455		38 39 41 42	8170942	Clip, Drain Tube Clamp Hinge, Top Cover, Hinge
11 12 13	8171003 8171002 4344186 8170373	Biscuit Black Screw	23 25	8170866 8170868 8170867 4343694 4344167	White Biscuit Black Screw	44	8170977 8170976 8170975 8170972	White Biscuit
14 15	4344198 8170980 8170981	Screw Hinge, Center Black	27 28		Cover, Water Valve	46 47	4344298	Foot Break Cabinet (Not A Serviceable Part)


FREEZER LINER PARTS



FREEZER LINER PARTS

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	8170897	Gasket, Foam
4	8170847	Cover, Control
6	8170839	Light Socket
9	4343660	Light Bulb
10	8170852	Housing, Frz. Light
11	8171082	Cover, Evaporator
14	8170848	Housing, Light
15	8170895	Clip, Evap. Motor
16	8170842	Switch, Light
20 22	8171083 8170881	Gasket, Bottom
22 25	8171153	Cover, Fan Shroud Shroud, Evap.Fan
25 27	8170544	Fan, Evaporator
29	8171086	Grommet(2)
30	8170894	Motor, Evaporator
37	8170851	Knob, Control
39	8170849	Cover, Frz. Control
41	8170850	Thermostat
47	4344385	Funnel-Drain
		(Includes 48 & 49,
		seal & gasket)
48	4344311	Seal
49	4344310	Gasket

REFRIGERATOR LINER PARTS




REFRIGERATOR LINER PARTS

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	8171026	Housing, Ref.
3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 20 21 24 25 27 28 29	8171027 4344571 8170832 8170834 8170835 8170836 8170838 4344395 8171040 8170848 8170841 8170845 8171041 8170839 4343660 8171034 8171028 8171028 8171029 8171030	Light Overlay Light Switch Cover, Ref. Light Housing, Timer Knob, Damper Knob, Gear Gear, Belt Housing, Light Screw (2) Tank, Water Grommet, Screw Gear, Damper Control, Damper Insulation, Damper Union Socket, Light Light Bulb Dispenser Timer, Defrost Cover, Control Belt, Damper Plate, Filter
	8171031	Housing, Water Filter Assembly
30 31 32	8171033 8171032 8171042	Cover, Filter Filter, Water Head, Filter Bypass
33 34 35 36 37 38 39 40	8171038 4344396 8171039 8171035 8171036 4343952 8171037 8170934	Clip, Waterline Screw Top, Dispenser Plate, Switch Switch, Limit Clip, Front Connector Tube, Water

REFRIGERATOR DOOR PARTS

For Models: KBRA20ELWH01, KBRA20ELBT01, KBRA20ELBL01, KBRA20ELSS01, KBLA20ELSS01 (White) (Biscuit) (Black) (Stainless Steel-RH)(Stainless Steel-LH)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door
		(Includes
	8171008	Insulation) White
	8171010	
	8170971	Black
	8170966	
3	8170969 8170794	
3 4	8170793	Tray, Dairy
5	8170751	Shelf Bin
6		(Medium) Plug, Handle Hole
Ü	8170791	White
	8170792	
7	8171018 8170956	
8	0170000	Door Gasket,
	0474044	Magnetic
	8171011 8170952	
9		Door Handle
	8171016	
	8171015 8171014	
		Stainless
10	8171017	Stud, Handle
11 12	4344296 8171019	Dish, Butter Shelf Bin (2)
		(Large)
13 14	8171021	Washer
15	8171012 8171020	Door Shelf Caddy, Can
17		Stop, Door
	4344463 8170494	
	4344563	
18		Plug, Button
	8170978 8170979	
21	4344333	
23		Bushing
	4344362 4344361	
24	+0++00 I	Plug, Button
	8170953	White
25	4343926	Black Nameplate
20	8170734	White .
	8170733	Bisquit
	8170732	Black

UNIT PARTS

UNIT PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 7	8171087 4344167	Blade, Fan Base	25 26 27 28	8171092 4344268	Clip, Heater Harness, Unit Drier Compressor (Includes Items 11, 12 and 39)		ptional	arts Not Illustrated Parts Not Included Valve, Access
8 9 10 11 12	8170908 8171085 8170724	Drain Pan Grommet (3) Evaporator Heater Clip Overload (Includes Relay and Capacitor)	31 32 34 39 40 42 43	8170901 4343845 4344562	Bracket, Fan Motor Clip, Drier Grommet (4) Screw Clip, Evaporator		978026 978027	(1/4") 5 Valve, Access (5/16") 7 Valve, Access (3/8") 8 Valve, Access (1/2")
13 14 15 18 20 22 23	8170912 8171091 8171081 8171084 8171155	Bi-Metal Grommet (7) Condenser Tray, Drip Evaporator Dam Right Side	44 53 54 55				978030	Valve, Access (5/8") Valve, Access (3/4") Valve, Access (3/16")
24		Left Side Motor, Fan				REF	RIGERA	5.0 Ozs. (R-134A)

SHELF PARTS



SHELF PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Glass, Pantry	18	8171052	Support, Crisper	31	8171060	Door, Pantry
2		Rack, Wine			Cover			Drawer
4	8171057	Support, Pantry(2)	19	8171048	Trim, Crisper	32	8170815	Basket, Freezer
5	8171056	Brace, Pantry(2)	20	8171047	Frame, Crisper			Lower
6	8171046	Track, Pantry	21	8171045	Glass, Crisper	33		Endcap, Basket
7	8171050	Seal, Front			Cover		8170816	Left
9	8171054	Gasket, Pantry	22	8171068	Ladder, Center		8170820	
10		Housing, Control	23	8171069	Ladder, Side	34	8171080	Divider, Lower
11	8171043	Shelf Assembly	24	4344396	Screw			Basket
12	8171044	Slide, Temperature	25	8170578	Screw	35	8171070	Basket, Freezer
13	8171051		26	4344333	Screw			Upper
		Crisper(2)	27	8171049	Slide, Humidity	36	8171071	Handle, Freezer
14	8171065	Glide, Drawer(2)			Control			Basket
15	4344523		28	8171064	Rod, Temperature	37	8171072	Divider, Upper
16		Track, Pantry			Control			Basket
	8171058	Left	29	8171061	Drawer, Pantry	38	8171073	Screw
	8171063		30	8171062	Knob, Temperature	39	8170709	Bin, Egg
17		Crisper(2)			Control			


ICEMAKER PARTS

For Models: KBRA20ELWH01, KBRA20ELBT01, KBRA20ELBL01, KBRA20ELSS01, KBLA20ELSS01 (White) (Biscuit) (Black) (Stainless Steel-RH)(Stainless Steel-LH) -16 33 ₂₃ 28²⁵ _26 -27

ICEMAKER PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	628228	Mold & Heater	13	4344397		31	4343702	•
2	4344265	Assembly	14 15	8170939	• · · · · · · · · · · · · · · · · · · ·	32 33	8171096	Valve, Primary
3		Bearing & Inlet	16		Wiring, Harness Clip, Ice Maker	34	8170926	
4	8170927	3	17	4344167		100		Complete Ice Maker
5		Ice Stripper	18	8170936		'00	1000110	Assembly
6		Support & Motor	19		Module Assembly			. 1000
•		Assembly	20		Valve, Solenoid			
7	8170930	Retainer,	21		Nut, Sleeve	Follo	owing Pa	rts Not Illustrated
		Thermostat(2)	22	8171098	Insert	l —	3	
8	627985	Thermostat	23	628379	Clip, Thermal			
		(Also Order			Fuse	l No	ote: The Fo	ollowing Parts Are
		542369 Cement	24	4344218				of Accessory Bag
		Alumilastic)	25		Compression Nut			Coupling
9	8170933	()	26		Insert, Tube			Tube Clamp
10		Fill Tube	27		Water Tube		4344549	Plug, Hole .
11	8170413	•	28	4343686				Plug, Button
		Water Valve	29		Clip, Wire			3 ,
12	8171097	Valve, Secondary Water	30	4343675	Screw			

FREEZER DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8171024 8171023 8171022 8170968	Biscuit	8	8171016 8171015 8171014 8170961 8171025 8170951 8170956	Biscuit Black Stainless Door Gasket, Magnetic White Black	14 18 19 20	8170978 8170979 8170953 4343926 8171021 8171017	Black Plug, Button White Black

OPTIONAL PARTS

For Models: KBRA20ELWH01, KBRA20ELBT01, KBRA20ELBL01, KBRA20ELSS01, KBLA20ELSS01 (White) (Biscuit) (Black) (Stainless Steel-RH)(Stainless Steel-LH)

Illus. Part No. No. DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and	Refi	nishing	Material	Misc	ellaneo	ous
Optional Parts (Not Included)		799340	Enamel, Black		212643	Sealer, Gum
Customer Touch-Up Material		799344	(1 Qt. Uncut) Enamel, White (1 Qt. Uncut)		479502	(4 Feet) Tape, Vinyl (3/4 x 108")
*350942 Primer, White (13 Oz. Spray Can) *350939 Enamel, Black		978883	B Enamel, Almond (1 Qt. Uncut)		876370	(3/4 x 100) Kit, Insulation (2 Pcs. x 3" x 24" X 48")
*350930 Enamel, White (13 Oz. Spray Can)					876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
*350956 Enamel, Almond (13 Oz. Spray Can) 72017 Brush Touch–Up Kit (White)					978941	Insulation, Fiberglass (63–1/2" x 35–1/2" X 2–5/8)
72107 Brush Touch-Up Kit (Almond) 72032 Brush Touch-up kit					876029	Kit, Foam Slab (30" x 32–1/2" x 1–1/2")
(Black)					505587	Sealer, Mastic (1 Qt.)
*•					503695	Cork, Sealer (1/4 Pound)
*Important: The spray paint is not to be used where the paint may make contact with the door						Touch-Up, White Porcelain (2 Oz.)
gaskets.					542638	Grease, Silicone (1/2 Oz.)
					542639	Cement, Alumilastic (1–1/4 Oz.)
					606755	Bag, Insulation (36–5/8" x 46")
					799833	Kit, Evaporator Repair
						(Aluminum Epoxy) Kit, Terminal Connector
					4343700	Ice Container Assembly
				TOR	X SCRE	W WRENCH

1117510 Torx Key